

ALL-WHEEL DRIVE

PARTS MANUAL FOR CT12H SERIES

MARMON-HERRINGTON ALL-WHEEL DRIVE

13001 Magisterial Drive • Louisville, KY 40223 (502) 253-0277 • (800) 227-0727 • Fax (502) 253-0317 E-mail: info@marmon-herrington.com

Visit our web site to view Repair & Parts Manuals www.marmon-herrington.com

TABLE OF CONTENTS

FORWARDWARRANTY POLICY AND PROCEDURE3-5CT12H SERIESDIFFERENTIAL CARRIER HOUSING CT12H6-7DIFFERENTIAL CT12H8-9AXLE HOUSING CT12H10-11AXLE SHAFT ASSEMBLY CT12H12-13WHEEL HUB, BRAKE DRUM CT12H14-15BRAKE CT12H16-17TIE-ROD CT12H18-19

ALL-WHEEL DRIVE

MARMON-HERRINGTON ALL-WHEEL DRIVE 13001 Magisterial Drive • Louisville, KY 40223 (502) 253-0277 • (800) 227-0727 • Fax (502) 253-0317 E-mail: info@marmon-herrington.com

GENERAL

This manual has been prepared for operators and service personnel working with the Marmon-Herrington series of transfer cases and front drive axles. For further technical assistance, please contact Marmon-Herrington Customer Service.

Please observe and follow all procedural and maintenance guidelines to ensure reliable operation and optimum service life. The Marmon-Herrington basic service schedule will integrate seamlessly with most preventative maintenance programs.

Marmon-Herrington shall not be liable for component failures or damages caused by operational abuse or neglect. Please review the Warranty Statement for a detailed explanation of coverage and claim reporting procedures.

We thank you for your investment in Marmon-Herrington equipment, and look forward to serving your needs in the tradition of engineering excellence.

MISCELLANEOUS ISSUES

Tires and Gear Ratios

When vehicles are still in the specification stage prior to construction, a great deal of thought and calculation goes into determining what tires and gear ratios will be best suited to the engine and transmission combination being used. This is especially true of AWD (all-wheel-drive) type vehicles because front and rear drive axles are interconnected through the transfer case, and therefore vulnerable to the adverse effects of differential tire speed. The most prominent of these adverse conditions is called "wind-up" which is caused by "ratio mis-match."

Effectively, this means that by virtue of different tire sizes or gear ratios from front to rear, one set of tires is trying to turn faster than the other. This generates excessive amounts of torque (wind-up) which is transmitted through the drive train. These extreme torsional loads can cause damage to differential gears, transfer cases, even engines and transmissions.

With the preceding in mind, the owner or operator should feel compelled to seek expert advice when considering alternative gear ratios or tires.

Operations

1) USE OF AWD MODE

Your Marmon-Herrington transfer case or axle may find itself paired with a front drive axle in an AWD application as previously described. If so, there are a few points of operational practice that will ensure a long, trouble free service life. In the tire and ratio discussion we demonstrated one source of drive train wind-up, and some of the undesirable effects. The same consequences may be experienced through yet a different mode of abuse.

As close as engineers try to match gear ratios and tires for a given application, the reality is that there will always be some degree of mis-match between front and rear axles. When a vehicle is operated on a hard, dry surface with the front axle engaged (AWD, 4x4, 6x6, etc.), the tires are not able to slip and relieving the torsional forces being generated.

As such, Marmon-Herrington equipped vehicles are designed for *"as needed"* AWD operation only, in "off-road" conditions. They are not intended to be driven in AWD mode on hard, dry surfaces.

2) SHIFTING OF AXLE OR TRANSFER CASE

Marmon-Herrington Axles and Transfer Cases use no clutching devises, and therefore should only be shifted when the vehicle is at a full stop. This applies to front axle engagement, high and low ranges, and locking differentials. The only exceptions are those vehicles equipped with Marmon-Herrington's **SAFE-T-SHIFT** system, which are calibrated to shift up to 4 mph.

SAFE-T-SHIFT

Marmon-Herrington Transfer Cases do not employ any clutching device, and therefore are not of a class that may be shifted "on the fly", or when the vehicle is in motion. This applies to shifting between HIGH and LOW ranges as well as engaging the front axle. Shifting on the fly results in two different types of internal and external damage. The first is degradation of the engagement teeth due to relative rotation of drive gears and shift collars. This type of damage can prevent the case from shifting normally, as the teeth become burred and cannot mesh.

The second condition imparts excessive shock loading throughout the entire drive train. This occurs when a shift is attempted at the precise moment of tooth alignment (gears meshing), and the shift is actually completed at excessive speed. This results in high torque loading that is transmitted through the transfer case, drive shafts, and axles. The extent of the damage possible increases proportionately with the vehicle speed.

Over the years we have tried to protect end users from this mode of failure with operational placards, audible warnings, and light signals. Despite these efforts, we have yet to fully discourage this destructive practice.

In December 2003 Marmon-Herrington developed an electronic management system called **SAFE-T-SHIFT** to help prevent shift on the fly events. It consists of a microprocessor that receives speed information from a remote sensor in the transfer case. The system is calibrated to activate the shift solenoids at the first detection of motion, and then cancel control functions at 4 mph.

The actual completion of a shift still relies on tooth alignment of the gear sets, and the vehicle may need to roll a few feet before the transfer case can shift. Because the system becomes active at first motion and maintains air pressure thereafter, it is possible to accelerate rapidly to a speed greater than 4 mph before tooth alignment occurs, completing the shift. In this case, the shift may occur at a speed great enough to cause shock damage. For this reason, it is essential that the operator let the vehicle "walk" or idle forward until the shift is complete before accelerating normally.

Shift Procedure

- 1. With the vehicle at a complete stop, select the desired range or front axle position.
- 2. Place the main transmission in gear.
- 3. Allow the vehicle to idle forward (or backwards) at walking speed until shift is completed.
- 4. Accelerate normally.

In the case of a manual transmission, ease the clutch out in low gear, allowing the vehicle to "walk" until shift is completed.

Some possible exclusions to the Safe-T-Shift program are those vehicles fitted with a transfer case mounted PTO, Freightliner factory conversions, and any with Rockwell transfer cases.

MARMON-HERRINGTON WARRANTY

This is to certify that we, Marmon-Herrington Company, Louisville, Kentucky, warrant each new chassis remanufactured, or assembly or part furnished for the remanufacture of a truck chassis against defects in material and workmanship under normal use and service. Marmon-Herrington's obligation under this warranty is limited to replacement of, at our factory, any part or parts thereof which shall, within one (1) year after delivery of such vehicle to the final user after installation of the all-wheel drive conversion kit, be returned to us with transportation charges prepaid, and which our examination shall disclose to our satisfaction to have been thus defective.

Marmon-Herrington will warrant covered components against defects in material and workmanship under normal use and service for the specified period. This warranty includes all internal components with the following exceptions: Exceptions include, but are not limited to wear items such as brake linings and drums, oil seals and bearings, which will be covered for a period of 12 months or 12,000 miles, which ever occurs first.

Failure to follow designated maintenance procedures and schedules, maintain required lubrication levels, or any form of operational abuse or misuse will void all warranty coverage expressed or implied.

Failure reporting and claims submission procedures are to be followed as outlined in the standard warranty guidelines

Service parts are manufactured to the same standards as production installed parts. However, since the installation thereof, as well as the age and condition of the receiving vehicle are beyond the control of Marmon-Herrington, Service Parts are warranted for a period of ninety (90) days or five thousand (5,000) miles whichever first occurs. All other regular warranty conditions apply.

On vehicles operating OVERSEAS, the determination of defects will be made at Marmon-Herrington Company, Louisville, Kentucky, from complete information supplied in writing by overseas distributors or recognized acting distributors. Complete information is defined to mean: vehicle serial number, user's name, date of delivery, mileage at time of breakage, date of breakage, type of service, nature of break or fault, distributor's recommendation (for our guidance only), and any other pertinent information. After determination of our obligation, any parts to be replaced will be shipped to distributor or acting distributor in accordance with his instructions.

This warranty is in lieu of all other warranties expressed or implied and of all other obligations or liabilities incurred by Marmon-Herrington. Marmon-Herrington neither assumes nor authorizes any other person to assume any other liability in connection with this sale, including but not limited to indirect or consequential damages.

This warranty shall not apply to any vehicle which shall have been repaired or altered in any way so as in our judgment, to affect its stability or reliability, nor which has been subject to misuse, negligence, or accident, nor which shall have been operated at a speed exceeding the factory rated speed or loaded beyond the factory rated load capacity or operated in violation of Marmon-Herrington's instructions.

Marmon-Herrington makes no warranty whatever on components of the original manufacturer's chassis not related

to the modification work. Also, no warranty is made on tires, rims, ignitions, or other parts usually warranted separately by their respective manufacturers.

The manufacturers reserve the right to make changes in design, and changes or improvements upon their product, without notice, and without incurring any obligation to install such changes or improvements upon their products theretofore manufactured.

This warranty shall become effective only when the Warranty Certificate has been returned to Marmon-Herrington and validated by the same.

In the case of vehicles operating in extreme conditions such as corrosive material mines, deep- water zones or areas of hostile aggression, the following warranty limitations apply:

Marmon-Herrington shall not be responsible for damage caused by chemical corrosion, internal water damage due to total immersion, or explosive impact. These conditions constitute severe duty and are not covered by Marmon-Herrington standard warranty.

WARRANTY REPAIR AND CLAIM PROCEDURE

Initial Failure Reporting

- 1. Operator must call Marmon-Herrington Customer Service prior to performing any repairs and receive a Repair Authorization Number to be eligible for reimbursement. The work authorization number does not guarantee payment but is an acknowledgement that the vehicle is within the warranty period in terms of date and mileage, and that a claim has been activated. It will be the responsibility of the operator to ensure that their repair facility is aware of, and complies with, the guidelines of this policy.
- 2. To expedite the authorization process, you will need the Sales Order Number or "S" number found on the front of this certificate. You will also need the Vehicle Identification Number or the last six digits of the "VIN", the date the vehicle was placed in service, and the current mileage. Please note the following:
 - This Warranty Registration should have been submitted at the time of delivery. If our records do not include a warranty registration, you must complete one before any authorization for repair can be issued. We will make them available by mail or fax upon request.
- 3. Marmon-Herrington will pre-approve .5 hours diagnosis/ inspection time prior to your call for repair authorization. If the the diagnosis/inspection complaint does not reveal a warrantable failure, or result in a warrantable repair, the customer will be responsible for all charges including diagnosis/inspection time.
- 4. The Operators Manual contains information covering proper equipment use and maintenance schedules. Operators must adhere to these guidelines to be eligible for reimbursement, and service records must be provided upon request.

Pre-Repair Requirements

1. Authorization for repairs will require a written estimate/repair order of costs after determination that a warrantable condition is found to exist.

- 2. Estimates must contain the following information:
 - A list of all parts necessary for specific job and if applicable, all parts that will be invoiced back to Marmon-Herrington.
 - The cost of disassembly, inspection and diagnosis of any portion of the vehicle to determine extent of repairs needed.
 - Current labor costs, reflecting both hourly rate and number of hours to effect repairs must be listed.
 - Miscellaneous charges such as "shop supplies" must be defined. Actual dollar amounts must be listed, as percentages will not be accepted.
 - Sublet repairs must also be defined and included in the estimate at their actual dollar amount.
 - NOTE: If it becomes necessary to exceed the original estimate in terms of parts or labor, the repair facility must call Marmon-Herrington Customer Service for additional authorization.
- Only the use of Marmon-Herrington supplied parts will constitute reimbursement unless prior approval has been obtained.

Parts Ordering

While Marmon-Herrington operates a full service Parts Department, replacement parts needed to effect Warranty repairs must be acquired through Customer Service to be eligible for reimbursement.

Post Repair Requirements

The final invoice or work order must include the following:

- Customer's name, address, and phone number.
- The Vehicle Identification number.
- The Sales Order Number or "S" number, which the customer can provide or can be located on the ID tag, fixed to the transfer case or axle.
- The Axle or Transfer Case Model and Serial Number, also located on the ID tag.
- Mileage In / Mileage Out.
- The Cause and Correction of the repair including detailed description of repairs and parts replaced.
- The date the repair order was open and the date the repairs were completed.
- The Work Authorization Number obtained from Customer Service.

Notes to Repair Facilities

- 1. Miscellaneous charges such as "shop supplies" must be listed as separate line items and shown on the final invoice as stated in "Pre-Repair Requirements." Invoices for sublet repairs must be made available upon request.
- All repairs must comply with any or all state and DOT requirements.
- Downtime of vehicle and incurred costs associated due to the delay of parts shipments or any other condition beyond our control is not reimbursable and should not be listed on the invoice.
- 4. All failed parts that are required to be returned to Marmon-Herrington must be received before payment will be made. The Return Authorization will be sent with the replacement parts when shipped from Marmon-Herrington.
- 5. All Claims must be submitted within 60 days of completion of repairs to be eligible for reimbursement.

For Work Authorization call: (80 To Submit Claims by Fax: (50

(800) 227-0727, Ext. 282 (502) 253-0317 Submit Claims by Mail to:

Marmon-Herrington Company, Customer Service Department, 13001 Magisterial Drive, Louisville, KY 40223.

REPLACEMENT PARTS

When ordering replacement parts for **MARMON-HERRINGTON ALL-WHEEL DRIVE** installations, the following information should be given:

- 1. **FACTORY ORDER NUMBER** (found on I.D. Plate or small plate affixed to axle housing). This will be a six (6) digit number. (See illustrations this page.)
- 2. Component for which parts are required, i.e. front drive axle or transfer case/drop box.
- Model of axle and/or transfer case/drop box, i.e. MT10, MVG 750, MDB500.
- 4. Give quantity and part number required. **NOTE:** Drivelines, shift linkage, etc., can be found on the computer printout of Bill of Material, which is included in the Service Manual.
- 5. Give complete billing and shipping address.

CALL IN PROCEDURE

Before proceeding with repairs or ordering parts that you feel may be covered under warranty, you must first contact Marmon-Herrington Customer Service Department to obtain a Repair Authorization Number.

(800) 227-0727, Ext. 282	8am-5pm EST
(502) 693-1129	5pm-8pm EST

Please be prepared to supply the following information:


Factory Order Number or "S-Number" This is located on an ID plate fixed to either the driver's door panel or the component (axle or transfer case) itself. This plate will also show the component's model and serial number. Example: S-7777-05

Component Model and Serial Number Vehicle Year, Make and Model Vehicle Identification Number Mileage In Service Date


Please refer to our website (www.marmon-herrington.com) for the latest versions of our parts and service manuals, as well as new products and contact information.

The information necessary for replacement parts and/or warranty claim procedures will be found on either plate design.


MARMON-HERRINGTON	TOOM DEP
SALES ORDER 0000-00 RATIO S/N TYPE CUST P/N	ALL-WHEEL DRIVE LOUISVILLE, KENTUCKY U.S.A. FACTORY ORDER NO. 0000-00
MARMON-HERRINGTON	INSTALLED BY
SALES ORDER 0000-00 S/N TYPE CUST P/N	FRONT DRIVING AXLE MODEL CAPACITY SERIAL NO.
COVERED BY ONE OR MORE OF THE FOLLOWING PATENTS: U.S. PATENTS 4,878,691; 4,934,733; 5,016,912; 5,275,430; 5,839,750; AND 6,398,251; AND CA PATENT 1,316,185. OTHER U.S. AND FOREIGN PATENTS PENDING.	RATIO



Othering Assistion Other Resonance Term No. Immediate No. Description Outling Assistion 1 0								
Image: Provision Assy. Image: Provision Assy.<	MH PART NO.		DESCRIPTION	ατγ. req.	ITEM NO.	MH PART NO.	DESCRIPTION	ΩΤΥ. REQ.
DIFFERENTIAL CARRIER HOUSING 0 <td< td=""><td>CT12-1040</td><td></td><td>Differential Carrier Housing Assy.</td><td>1</td><td></td><td></td><td></td><td></td></td<>	CT12-1040		Differential Carrier Housing Assy.	1				
, DIFERENTIAL CARRIER HOUSING	CT12-1078		Flanged Bolt, Special	4 (
, P = P = P = P = P = P = P = P = P = P =	CI12-10//		Flanged Bolt, Special	∞ -				
, 2 2 4 4 4 4 4 4 4 4 4 4 4 4 4	MI 10-1041 CT8-1054		rrex bolt, Special Washer	4 4				
, 1 - 7 4 - 7	MT10-1043		Taper Roller Bearing	2				
, 4 4 4 4 4 4 4 4 4 4 4 4 4	MT10-1044		Bearing Adjuster	2				
12 4	MT22-1080	_	Adjuster Lock Plate	-				
DIFFERENTIAL CARRIER HOUSING	11500773		Hex Bolt, M8x16-1.25	4				
DIFFERENTIAL CARRIER HOUSING								
DIFFERENTIAL CARRIER HOUSING								
DIFFERENTIAL CARRIER HOUSING								
DIFFERENTIAL CARRIER HOUSING								
DIFFERENTIAL CARRIER HOUSING								
DIFFERENTIAL CARRIER HOUSING								
DIFFERENTIAL CARRIER HOUSING								
CT12H	RRINGTO al Drive • Lo • (800) 227- armon-herri	uis 072 ing	DIFFE	riAL CA CT1	ARRIEF 12H	ISUOH F	NG	PM05/06




COM	COMPLETE CARRIER ASSEMBI	ВЦҮ	ITEM NO.	MH PART NO.	DESCRIPTION	ατγ. reg.
CARRIER P/N	PINION & RING GEAR RATIO	DIFFERENTIAL CASE	11	MT10-1062 MT10-1063	Hex Bolt, Special Self-Lock Nurt	ωα
CT12-1011	4.11	CT12-1021	i τ τ	CT12-1064	Bearing Cage) (
C112-1012	4.33	C112-1021	14	MT10-1065	Flanged Bolt, Special	9
CT12-1001	4.62	CT12-1021	15	MT10-1066A	Shim, 1.00 MM	AR
CT12-1013	4.70	CT12-1021		MI10-1066B		Y C
CT12-1002 CT12-1003	00; r	CT12-1021		MI10-1066C		H K
CT12-1015	5.38	CT12-1023		MI 10-1066U		Ч С Ч
CT12-1004	5.57	CT12-1023	Ű	MI 10-1006E	Bolloz Booring	AH -
CT12-1005	5.86	CT12-1023	0 [018-10/2	Roller bearing	– c
CT12-1006	6.14	CT12-1023		MI 10-1068	Plnion Bearing, Inner and Outer	N
CT12-1009	6.50	CT12-1023	8 9	MI10-1069	Oll Seal, Pinion	- 1
CT12-1007	6.83	CT12-1023	61 00	CT12-10/1	Companion Flange Self-Lock Nurt	
CT12-1008	7.17	CT12-1023	51 5	MT10-1074A	Dinion Bearing Spacer 13 950 MM	- ¤
ITEM NO. MH PART NO.	DESCRIPTION	QTY. REQ.	- J	MT10-1074B	Spacer,	AR*
				MT10-1074C		AR*
1 CI12-1021	Differential Case Assy. (4.11-5.29)			MT10-1074D	Spacer.	AR*
CI12-1023	Differential Case Assy. (5.38-7.17)			MT10-1074E		AR*
-	Both of the above each include Items 1 & 2			MT10-1074F	Spacer. 14.075	AB*
	Hex Bolt, Special	12		MT10-1074G	Spacer. 14.100	AB*
	Hex Bolt, M6x12	4		MT10-1074H	Spacer 14 125	AB*
4 MT11-1027	Oil Scoop	5		MT10-1074I	Spacer, 14,150	AB*
	Differential Cross	-		MT10-1074.1	Snacer 14 175	AR*
	Differential Pinion	4		MT10-1074K	Sharer 14 200	ΔΠ.*
7 CT12-1063	Washer, Differential Pinion Gear	4			Cpacel, 17.200	
8 MT22-1059	Washer, Differential Side Gear	2		MI 10-10/4L	Spacer, 14.223	
9 CT12-1064	Differential Gear	5		MH10-10/4M	Spacer, 14.250	ЧЦ ЧЧ
	Rind Gear and Pinion 4 11			MT10-1074N	Spacer, 14.275	AR*
	Rind Gear and Pinion 4.33			MT10-1074P	Spacer, 14.300	AR*
CT12-10-20	Rind Gear and Pinion 4.60			MT10-1074Q	Spacer, 14.325	AR*
	Ding Gear and Finon 4.02			MT10-1074R	Spacer,	AR*
		- •		MT10-1074S	Pinion Bearing Spacer, 14.375 MM	AR*
	Gear and			MT10-1074T		AR*
	Gear and	- •		MT10-1074U		AR*
C112-1031		- ,		MT10-1074V	Pinion Bearing Spacer, 14.450 MM	AR*
C112-105/	Gear and	- ,		MT10-1074W	Spacer,	AR*
C112-1058	Hing Gear and Pinion 5.86	- ,		MT10-1074X	Spacer,	AR*
C112-1059	Gear and			MT10-1074Y	Spacer,	AR*
C112-1032	Gear and	- ,		MT10-1074Z	Spacer, 14.550	AR*
C112-1060	Hing Gear and Pinion 6.83	- ,			AR = As Required	
CI12-1061	Hing Gear and Pinion 7.17	-			*Note: Choose 2 to produce proper bearing preload	oreload.
MARMON-HERRINGTON ALL-WHEEL DRIVE 13001 Magisterial Drive • Louisville, KY 40223 (502) 253-0277 • (800) 227-0727 • Fax (502) 253-0317	ALL-WHEEL DRIVE sville, KY 40223 27 • Fax (502) 253-0317	DIFFERENTIAI CT12H	ERENTIAL CT12H		WOOD-	
E-mail: into@marmon-herrington.com	gton.com	-			حر الـ	PM05/06



- 10 -


ITEM NO.	MH PART NO.	DESCRIPTION	ατγ. κεα.	ITEM NO.	MH PART NO.	DESCRIPTION	QTY. REQ.
	CT12-1075	Axle Housing	÷	27	MT10-1095	Bushing	N
0	MT14-1070	Fill Plug	-	28	MT10-1096	Tie-Rod Arm, L.H.	-
Ю	MT14-1071	Magnetic Drain Plug, M24x1.5	-		MT10-1137	Tie-Rod Arm, R.H.	-
4	MT14-1068	Vent	-	29	MT93-2308	Key	m
5	MT10-1076	Snap Ring	4	30	103415	Cotter Pin	က
9	MT10-1077	Cylindric Roller Bearing	2	31	MT10-1099	Castle Nut	က
7	MT22-1116	Oil Seal	2	32	MT10-1100	Turn Stop Bolt	N
Ø	MT10-1079	Oil Seal Support Assy.	2	33	MT10-1101	Jam Nut	N
	MT10-1080	Felt Wiper	2	34	MT93-2307	Steering Arm	-
6	MT10-1081A	Shim, 0.40 MM	AR	35	MT22-1132	Spindle Nut	4
	MT10-1081B	Shim, 0.60 MM	AR	36	MT22-1133	Lock Plate	N
	MT10-1081C	Shim, 1.00 MM	AR	37	MT10-1103	Lock Disk	Ŋ
	MT10-1081D	Shim, 1.20 MM	AR	40	MT10-1108	Spindle, L.H.	÷
	MT10-1081E	Shim, 1.40 MM	AR		MT10-1109	Spindle, R.H.	F
10	MT10-1132	Lock Pin	4	41	MT10-1105	Hex Flange Bolt	24
=	MT10-1133	Flanged Nut	4	43	MT93-1109	Sensor Holder	0
12	MT10-1082	Taper Roller Thrust Bearing	2	44	11500713	Hex Bolt	4
13	MT10-1150	Steering Knuckle Assy., L.H.	-	45	11500191	Lock Washer	4
	MT10-1084	Steering Knuckle Assy., R.H.	-	46	MT93-1283	Clamp Sleeve	0
14	MT10-1087	Grease Seal	4	47	CT8-1091	Revolution Sensor	N
15	MT10-1088	Bushing-Knuckle Pin	4	48	CT8-1092	Connecting Holder	-
16	MT10-1089	Kingpin Upper	0	49	CT8-1093	Holder Plate	N
17	MT10-1090	Cap	4				
18	MT14-1119	Grease Fitting 45°	9				
19	MT10-1091	Kingpin Lower	0				
20	MT10-1092	Gasket	4				
21	11500716	Hex Bolt	12				
22	11500191	Lock Washer	12				
23	MT14-1092	Oil Seal	2			AR = As Required	
24	MT10-1094	Dust Plate	2				
25	11500190	Lock Washer	8				
26	11503946	Hex Bolt, M6x12	8				
MARMON-H		JRIVE	AXI F HOUSING	NISHC	C		
(502) 253-027	13001 Maglisterial DTIVE • LOUISVIILE, N.1 40223	40223 (502) 253-0317	CT12H	2H	5	100 PP	
E-mail: into@	E-mail: into@marmon-herrington.com	jton.com	•				PM05/06

| | |




ITEM NO.	MH PART NO.	DESCRIPTION	QTY. REQ.	ITEM NO.	MH PART NO.	DESCRIPTION	ατγ. reg.
-	CT12-1110	Axle Shaft Assembly, L.H., Long	-				
	CT12-1111	Axle Shaft Assembly, R.H., Short	1				
2	MT22-1147	Cardan Joint Assembly	2				
ю	MT10-1112	Outer Axle Shaft	2				
4	CT12-1113	Inner Axle Shaft, L.H., Long	-				
	CT12-1114	Inner Axle Shaft, R.H., Short	-				
2	MT22-1225	Joint Hub	2				
9	MT22-1226	Spider	NSS				
7	MT22-1227	Bearing Cap Assembly 7/8"	NSS				
ω	MT22-1228	Snap Ring	16				
6	MT22-1229	Taper Screw Plug, M12x1.5	16				
10	MT22-1230	Joint Pin	4				
11	MT22-1231	Set Screw	4				
12	MT22-1232	Bearing Cap Assembly 1 ["]	NSS				
		NSS = Not Sold Separately					
MARMON-F 13001 Magist (502) 253-027 E-mail: info@	MARMON-HERRINGTON ALL-WH 13001 Magisterial Drive • Louisville, KY (502) 253-0277 • (800) 227-0727 • Fax (E-mail: info@marmon-herrington.com	EEL DRIVE 40223 (502) 253-0317	AXLE SHAFT ASSEMBLY CT12H	- ASSE 12H	MBLY	PMOS/06	PM05/06

— 13 —




I EM NO.	WIT FART NO.	DESCRIPTION	מוז. אבע.	I EM NO.	WIT FART NU.	DESCRIPTION	<u>и</u> т. не
-	MT11-1226	Hub Assembly (MT11H/CT12H)	N				
	MT11-1025	Wheel Hub Only	N				
2	MT93-1250	Wheel Stud (MT11H/CT12H)	20				
	MT93-1838	Nut (MT11H/CT12H)	20				
с	MT10-1043	Wheel Bearing, Outer	2				
4	MT93-1108	Impulse Ring	2				
£	MT10-1121	Wheel Bearing, Inner	2				
9	MT10-1123	Hub Seal	2				
7	MT11-1026	Brake Drum (MT11N/H/CT12H)	2				
8	11500723	Hex Bolt, M10x20-1.5	4				
6	MT10-1051	Cover	2				
10	11500713	Hex Bolt	8				
1	MT10-1124	Snap Ring	2				
12	MT10-1050	Drive Flange	2				
13	2T351	Hex Bolt	16				
14	103323	Washer	16				
			·				
			·				
			·				
MARMON-F 13001 Magist (502) 253-027	HERRINGTON / terial Drive • Louis 77 • (800) 227-075	IEEL DRIVE WI 40223 WI (502) 253-0317 WI	. HUB, I	BRAKE	HEEL HUB, BRAKE DRUM	YOUNDE	The Contraction of the Contracti
E-mail: info€	È-mail: info@marmon-herrington.com		5				PM05/06

— 15 —



— 16 —

— 17 —							
ITEM NO.	MH PART NO.	DESCRIPTION	ατγ. reg.	ITEM NO.	MH PART NO.	DESCRIPTION	ατγ.
-	CT12-1164	Brake Shoe Assembly	4				
N	MT14-1157	Return Spring, Short	4				
ю	MT14-1156	Return Spring, Swivel-Ends	4				
4	MT11-1004	Spring Support Pin	4				
5	MT11-1005	Roller Pin	4				
9	MT11-1006	Brake Shoe Roller	4				
7	MT11-1007	Brake Support, LH	Ļ				
	MT11-1008	Brake Support, RH	-				
8	MT22-1180	Bushing	4				
6	MT22-1179	Oil Seal	4				
10	MT14-1132	Grease Fitting	N				
11	MT10-1105	Hex Bolt	24				
12	MT11-1010	Air Chamber Bracket, LH Assy.	-				
	MT11-1011	Air Chamber Bracket, RH Assy.	-				
13	MT22-1183	Hex Bolt	9				
14	11500194	Lock Washer	9				
15	MT14-1142	Spacer	Ŋ				
16	MT11-1012	Camshaft, LH	-				
	MT11-1013	Camshaft, RH	-				
17	MT11-1014	Spacer	Ŋ				
18	MT11-1015	Shim, 0.5 MM	AR				
19	MT11-1123	Auto Slack Adj., LH (MT11N/H/CT12N/H)	-				
	MT11-1124	Auto Slack Adj., RH (MT11N/H/CT12N/H)	-				
20	MT11-1017	Washer	N				
21	MT11-1018	Snap Ring	2				
22	MT22-1239	Auto Slack Stop, LH	-				
	MT22-1240	Auto Slack Stop, RH	1				
23	MT11-1019	Dust Shield	2				
24	MT11-1020	Rubber Plug	4				
25	11500773	Hex Bolt M8x16	14				
26	11500191	Lock Washer M8	14				
27	11500289	Washer M8	10			AR = As Required	
MARMON-F 13001 Magiste	HERRINGTON A erial Drive • Louis	MARMON-HERRINGTON ALL-WHEEL DRIVE 13001 Magisterial Drive • Louisville, KY 40223 1500) 553-0277 • (800) 927-0727 • Eav (500) 553-0317	BRAKE			- TEL MONT	
E-mail: info@	E-mail: info@marmon-herrington.com	ton.com	CITZH	HN		ral . han	PM05/06



19 —							
ITEM NO.	MH PART NO.	DESCRIPTION	ατγ. κεα.	ITEM NO.	MH PART NO.	DESCRIPTION	ατγ. reg.
	CT12-1127	Tie-Rod Assembly	÷				
2	CT12-1128 CT12-1128	Ball Joint Head, Left	÷ •				
	CT12-1123	Tia-Bod Tuhe with Clamos					
04	11500735	Hex Bolt, M12x65-1.75	- വ				
5	11500756	Nut, M12-1.75	2				
9	103411	Cotter Pin, 3/16x2	N				
DN-F agist 3-027 info@	IERRINGTON / erial Drive • Louis 7 • (800) 227-072 ?marmon-herring	MARMON-HERRINGTON ALL-WHEEL DRIVE 13001 Magisterial Drive • Louisville, KY 40223 (502) 253-0277 • (800) 227-0727 • Fax (502) 253-0317 E-mail: info@marmon-herrington.com	TIE-ROD CT12H	ROD 12H		PMOS/OG	PM05/06

MARMON-HERRINGTON

ALL-WHEEL DRIVE

13001 Magisterial Drive • Louisville, KY 40223 (502) 253-0277 • (800) 227-0727 • Fax (502) 253-0317 E-mail: info@marmon-herrington.com

www.marmon-herrington.com